



## C-144KT-806 VACUUM BREAKER REPLACEMENT KIT

### REPLACEMENT PARTS FOR PRIER C-144/244 SERIES WALL HYDRANTS

#### Instructions

1. Turn off the water supply to your wall hydrant before replacing these parts.
2. Remove the green plastic vacuum breaker cap from the wall hydrant in a bottle opening motion using a flat-headed screwdriver.
3. Using channel-lock pliers, remove the body of the vacuum breaker body by grasping it and turning it in a counter-clockwise direction until the vacuum breaker body is removed from the valve. Remove the poppet from the inside of the housing.
4. Assemble the vacuum breaker body into the valve until it is tight. It is critical for the new poppet to be installed so the rubber-sealing surface is in the “up” position to seal the vent hole in the vacuum breaker body.
5. Test the valve by turning on the water to the wall hydrant and test for leakage. Reinstall the vacuum breaker cap by snapping it on the vacuum breaker body.

