



Installation, Operation & Maintenance Instructions for PRIERs P-7335 Recessed Wall Mounted Bottle Filler Station

Build With Purpose

Please leave this sheet for the property homeowner

Thank you for purchasing PRIERs Recessed Wall Mounted Water Bottle Filler Station. To ensure this product is installed properly, please read these instructions carefully before you begin. (*Certain installations may require professional help.*) **IMPORTANT:** For installing outdoor Bottle Filler, observe local plumbing and building codes. **Note:** Pictures may not exactly define contour of components

GENERAL INFORMATION

1. See Stern-Williams Dimensional Information sheet for drawings of the bottle filler and mounting plate.
2. The 4 outermost 25/64" (.39") holes are the mounting holes. Depending on the wall construction (wood, concrete, etc.), 3/8" screws or bolts will go through these holes to attach to the structure. You need structural support at these locations.
3. The back of the bottle filler has 4 coupling nuts 1 1/2" long. The bottle filler attaches to the mounting using these nuts. Four 1/2" bolts fit through the 5/8" holes in the mounting plate and screw into the coupling nuts. This will be the last step in mounting the bottle filler.
4. Therefore, for the front of the bottle filler to be flush with the outside wall, the mounting plate needs to be recessed 1 1/2" into the wall.

ATTACH BOTTLE FILLER TO WALL

1. Locate where bottle filler will be installed on the wall. We recommend 27" above the finished floor.
2. Depending on the method of construction, make a 1 1/2" deep recess into the wall the size of the outside of the mounting bracket (14 1/2" wide x 24" tall).
3. The space on the inside of the bracket needs to be open for the bottle filler to fit inside the bracket and to access hardware on the backside. If it is not already open, use the inside of the mounting plate as a template and cut out any wall structure. Space behind the four 5/8" holes also has to be clear to fit the 1/2" bolts.
4. Set the mounting plate into the recess and anchor it to the wall structure using the 4 outer most holes as mentioned above.
5. Hold the bottle filler up to the mounting plate while aligning the 4 coupling nuts and thread the four 1/2" bolts through the back of the mounting plate into the coupling nuts. The bottle filler is now secured to the wall.

CONNECT PLUMBING

1. Connect drain at the bottom of the bottle filler to the drain line.
2. Connect water supply to the push button assembly near the top of the bottle filler.
3. Push button to assure proper flow. Adjust flow using Allen wrench in center hole.